


EQUIPAXIS AUTOCLAVE

DIAGRAM: PARTS & FUNCTIONS



REMEMBER!

- Do not open the lid while pressure exists.
- Use suitable materials as per guidelines.
- Always follow the operating manual and safety instructions.